

T3.91

Permanent anti-stain process for natural quartzite

MATERIALS

- Natural quartzite

APPLICATION FIELDS

- Floorings
- Stairs
- Coverings
- Kitchen Countertops
- Bathroom Countertops
- Tables



CHARACTERISTICS

- Solvent based
- It could change the colour of the surface
- It gives the surface a natural effect
- Excellent water-repellent
- Impregnating with complete absorption
- Permanent anti-stain treatment easy to apply without machines
- The primer modifies permanently the porosity
- The anti-stain makes it unassailable the stone from stains
- It does not turn yellow over time
- The natural quartzite no corrodes with acid substances
- It protects against staining substances such as oil, coffee, greases, wine, ect...

PACKAGING

- Box of 20 Pcs composted of 0,25 + 0,25 Lt/Kg
- Box of 20 Pcs composted of 0,5 + 0,5 Lt/Kg
- Box of 6 Pcs composted of 1 + 1 Lt/Kg
- Box of 4 Pcs composted of 2 + 2 Lts/Kgs

WARNINGS

Apply at an ambient temperature between 10°C - 20°C. Keep out of reach of children. Do not disperse into the environment. Before use, consult the safety data sheet and label, in which risks and safety are highlighted for the correct use of personal protective equipment. All information contained in this page is based on information we believe to be reliable; however, not knowing the conditions of the materials treated and the way you use the product, ITALIAN XS declines all responsibility about The suitability of the material for each particular application. Store the product in the original containers and hermetically closed. Store the product at a temperature between 5° C - 20° C. If stored as indicated above, the product has a shelf life of 12 months. It is advisable to carry out preventive tests on small areas as our responsibility is limited at the cost of the product. No liability for damage caused by negligence or misuse of the product.

INSTRUCTION

SHAKE BEFORE USING

STEP 1: Ready to use product. On clean and dry surfaces apply T3.91 PRIMER spread it uniformly with a roller.

Uniform application with a microfibre cloth making circular rubbing. Depending on the absorbment of the surface apply the second coat just after the first. Before applying T3.91 TREATMENT let it dry 24-48 hours depending on the temperature.

STEP 2: Ready to use product. After 24-48 hours from STEP 1 on dry surfaces apply T3.91 TREATMENT spread it uniformly with a microfibre cloth. Depending on the absorbment of the surface apply the second coat just after the first.

COVERAGE

Approximate coverage: 1 Lt x 8 - 15 m²
Depending on the surface to be treated